


SuperStack II



SuperStack® II Baseline Dual Speed Hub 12-Port TP (3C16592A) and 24-Port TP (3C16593A) User Guide



INTRODUCTION

The SuperStack® II Baseline Dual Speed Hub is an easy-to-use, 10/100 autosensing Class II hub (repeater). It is ideal for users who want to connect both Ethernet and Fast Ethernet devices (workstations and other equipment) to the same hub.

All ports on the Baseline Dual Speed Hub are half duplex, autosensing 10 Mbps and 100 Mbps. Each port senses the speed of the connected equipment and operates at the appropriate speed.

The Baseline Dual Speed Hub comes with:

- One power cord for use with the Baseline Dual Speed Hub
- Four full height and two reduced height, self-adhesive rubber pads
- One rack mounting kit
- A Registration Card and Envelope for you to fill in and return
- This Guide

The Baseline Dual Speed Hub is suitable for office use where it can be free standing or rack-mounted (in a wiring closet or equipment room). The hub can be powered either from the AC mains supply, or through an optional 3Com® SuperStack II Advanced Redundant Power System (3C16071A). Contact your supplier for details.

Network Connections

The Baseline Dual Speed Hub has 12 or 24 shielded RJ-45, 10/100 autosensing ports on the front panel. Each port can be connected to either a 10BASE-T (Ethernet) or a 100BASE-TX (Fast Ethernet) device.

Internally, the hub has two repeater segments (10 Mbps and 100 Mbps) which are linked by a switch, allowing connected 10 Mbps and 100 Mbps devices to communicate.

You can connect a 10BASE-T or 100BASE-TX hub or switch to the Baseline Dual Speed Hub.



HOW TO USE THE BASELINE DUAL SPEED HUB




Figure 1 Numbered elements in this diagram refer to numbered sections in the text. A 24-port Hub is shown.

Front Panel

1 12 or 24 RJ-45 10/100 Ports

You can use these ports to connect 10BASE-T or 100BASE-TX devices (workstations and other equipment) to the Baseline Dual Speed Hub. As the ports are autosensing, the speed of the ports is determined automatically when you connect your equipment.

- WARNING: RJ-45 ports.** These are shielded RJ-45 data sockets. They cannot be used as telephone sockets. Only connect RJ-45 data connectors to these sockets.
- AVERTISSEMENT: Les ports RJ-45.** Ceux-ci sont les prises de courant de données RJ-45 protégées. Ils ne peuvent pas être utilisés comme prises de courant téléphoniques. Brancher seulement les connecteurs RJ-45 de données à ces prises de courant.
- WARNUNG: RJ45-Anschlüsse.** Hierbei handelt es sich um abgeschirmte RJ-45 Datenbuchsen, die nicht als Telefonbuchsen verwendbar sind. Nur RJ-45 Datensteckverbinder an diese Buchsen anschließen.

Connect one end of the TP (twisted pair) cable to the RJ-45 port on the Baseline Dual Speed Hub and the other end to the appropriate RJ-45 port on the device. Use either shielded or unshielded data cables (with shielded or unshielded jacks) to connect to the devices.

- i** The equipment that is connected to the Baseline Dual Speed Hub must not be set to operate in full duplex mode. It must be set to operate in autonegotiate or half duplex mode.


10BASE-T

To connect 10BASE-T equipment, use 10BASE-T Category 3 or Category 5 unshielded or shielded (screened) 100 Ohm TP cable.

- i** Category 5 cable should be used with this product in structured wiring environments. This will ensure correct operation of all ports at 10 Mbps or 100 Mbps.

Ethernet Network Configuration Rules

To remain within IEEE 802.3 10 Mbps Ethernet rules, the maximum length of cable between the Baseline Dual Speed Hub and an attached device must not exceed 100 m (328 ft). If you are connecting multiple hubs in series, ensure that there are no more than four 10 Mbps hubs between any two devices on your network, as shown below.




100BASE-TX

To connect 100BASE-TX equipment, use 100BASE-TX Category 5 unshielded or shielded (screened) 100 Ohm TP cable.

Fast Ethernet Network Configuration Rules

To remain within IEEE 802.3 100 Mbps Fast Ethernet rules, the maximum length of cable between the Baseline Dual Speed Hub and an attached device must not exceed 100 m (328 ft). Ensure that there are no more than two 100 Mbps hubs between any two devices on your network, and that the total cable distance (A+B+C) between the two devices does not exceed 205 m (672.4 ft), as shown below.




- i** If you connect two Baseline Dual Speed Hubs together, the link between them operates at 100 Mbps.

2 MDI Switch

This switch affects port 12 (3C16592A) or port 24 (3C16593A). Ports 1-11 (3C16592A) or 1-23 (3C16593A) are fixed as MDIX ports. Each can be connected to a device with an MDI port (such as most workstations) using a normal "straight through" TP cable. Port 12 or 24 is "switch selectable" using the MDI switch:

- Out** In this position, port 12 or 24 is an MDIX port. It can be connected to a device with an MDI port (such as most workstations) using a normal "straight through" TP cable.
- In** In this position, port 12 or 24 is an MDI port. It can be connected to an MDIX port on a device (such as another hub) using a normal "straight through" TP cable.

To connect the hub to a 10 Mbps or 100 Mbps unit, connect an MDIX port on the unit to port 12 or 24 on the Hub, as shown below. Ensure that the MDI switch on the Hub is in (MDI). If an MDI/MDIX port is used on the other unit, ensure that the MDI switch for that port is out (MDIX). Alternatively, you can use "cross-over" TP cable to connect any MDIX port on the Baseline Dual Speed Hub to any MDIX port on another unit.



3 Status LEDs

The Status LEDs show the state of a port and whether or not the Link Pulse signal is present on the segment connected to a port:

Green	A 100 Mbps Link Pulse signal is being received and the 100BASE-TX segment attached to the port is functional.
Yellow	A 10 Mbps Link Pulse signal is being received and the 10BASE-T segment attached to the port is functional.
Flashing	The port has partitioned, due to an excessive number of collisions, excessively long collisions, or a network loop. To remove a network loop, examine your connections and ensure that each piece of equipment is connected to your network by only one connection.
Off	The Link Pulse signal is not being received. Either nothing is connected to the port, or there is a problem: <ul style="list-style-type: none">■ Check that the attached device is powered on.■ Check that the cable is the correct type and is not faulty.

If the LED is off for port 12 or 24, check the setting of the MDI switch. Refer to **2**. Try toggling the MDI switch.

If you have connected different types of unit together, check that your configuration conforms to the network configuration rules for 10BASE-T and 100BASE-TX.

If the port is connected to another unit's MDI/MDIX port, check the other unit's MDI switch position.

If these checks do not identify the cause of a problem, it may be that the unit or the device connected to the port is faulty. Contact your supplier for further advice.

4 Segment LEDs

The Segment LEDs indicate activity on the 10 Mbps and 100 Mbps segments:

Flashing green	Packets are being received or transmitted.
Flashing yellow	Collisions are occurring on the segment. A low level of collisions is a part of normal Ethernet and Fast Ethernet operation. Excessive collisions may indicate a network problem.
Off	No packets are being received or transmitted on the segment.

5 Power LED

The Power LED indicates a number of conditions:

Green	The unit is powered on and ready for use.
Off	The unit is powered off. If the power cable is connected correctly, there may be a problem with the fuse within the power cord's plug. If the unit appears to be operating and the LED is off, contact your supplier.

Rear Panel Connections

6 Power Supply

The Baseline Dual Speed Hub automatically adjusts to the supply voltage. Only use the power cord that is supplied with the Baseline Dual Speed Hub, or a power cord of the same type and rating.

7 Socket for Redundant Power System

You can connect a 3Com SuperStack II Advanced Redundant Power System (ARPS) (3C16071A) to the Hub. The ARPS is designed to maintain the power to your Hub if a power supply failure occurs.

For normal redundancy, the ARPS requires one Type 1 Power Module (part number 3C16072). For full redundancy, the unit requires two Type 1 Power Modules combined using a Type 1 Y-Cable (part number 3C16079). Contact your supplier for further details.

8 Self-adhesive Pads

The hub is supplied with six self-adhesive rubber pads: two reduced height and four full height.



You do not need to apply the pads if you intend to rack mount the unit.

If you are placing the units one on top of the other, you must use the self-adhesive rubber pads supplied. Apply the pads to the underside of each unit, sticking one in the marked area at each corner. Place the units on top of each other, ensuring that the pads of the upper unit line up with the recesses of the lower unit. Use the two thinner pads when stacking the unit with a narrower one above.

Positioning the Baseline Dual Speed Hub



CAUTION: When installing the Baseline Dual Speed Hub in a stack of different size units, the Baseline Dual Speed Hub must be installed above any larger units. Do not have a free standing stack of more than six units.

When deciding where to position the Baseline Dual Speed Hub ensure:

- It is accessible and cables can be connected easily.
- Cabling is away from:
 - Sources of electrical noise such as radios, transmitters and broadband amplifiers.
 - Power lines and fluorescent lighting fixtures.
- Water or moisture cannot enter the case of the unit.
- Air flow around the unit and through the vents in the side of the case is not restricted (3Com recommend that you provide a minimum of 25 mm (1 in.) clearance).

To prolong the operational life of your units:

- Never stack units more than six high if free standing, and ensure that cables are supported so that they do not cause the stack to fall over.
- Do not place objects on top of any unit or stack.
- Do not obstruct any vents at the sides of the case.

Rack Mounting

The Baseline Dual Speed Hub can be mounted in a 19-in. equipment rack. Refer to the "Mounting Kit Instructions" section in this guide.

Power Up

Use the following sequence to power up the Baseline Dual Speed Hub:

- 1 Check the network connections and cables.
- 2 Connect the power supply cable to the appropriate power socket on the rear panel of the unit; refer to **6** or **7**.
- 3 Connect the plug to the mains power supply outlet socket. If you are using the Advanced Redundant Power System refer to the ARPS User Guide.

When the Baseline Dual Speed Hub is powered on, the Power LED should be lit. If it is not, refer to **5**, "Power LED".



MOUNTING KIT INSTRUCTIONS

The Baseline Dual Speed Hub is supplied with two mounting brackets and four screws. These are used for rack mounting the unit. When mounting the unit, you should take note of the guidelines given in "Positioning the Baseline Dual Speed Hub" on page 3.


The Baseline Dual Speed Hub is 1U high and will fit a standard 19-inch rack.



CAUTION: Disconnect all cables from the unit before continuing. Remove the self-adhesive pads from the underside of unit, if already fitted.

To rack mount the unit:

- 1 Place the unit the right way up on a hard, flat surface with the front facing towards you.
- 2 Locate a mounting bracket over the mounting holes on one side of the unit, as shown in the diagram.
- 3 Insert the two screws supplied in the mounting kit and fully tighten with a suitable screwdriver.
- 4 Repeat the two previous steps for the other side of the unit.
- 5 Insert the unit into the 19-in. rack and secure with suitable screws (not provided).
- 6 Reconnect all cables.



PROBLEM SOLVING

Refer to the information about LEDs given earlier in this guide to see if the problem can be identified and rectified. If the problem persists and the Baseline Dual Speed Hub still does not operate successfully, contact your supplier with the following information before returning the unit:

- Product number and serial number (printed on a label on the rear of the unit)
- A brief description of the fault

When returning any equipment to your supplier ensure that the equipment is packed suitably for transit.



Some older NIC (network interface card) cards were developed before the standardization of the auto-negotiation protocol. These may cause the Baseline Dual Speed Hub to sense the speed of the network incorrectly. We strongly recommend that you install the latest versions of the NIC drivers before connecting your network. 3Com NIC card drivers dated before 23/03/95 should be updated from the 3Com website.



TECHNICAL INFORMATION

The SuperStack® II Baseline Dual Speed Hub has been designed and certified to the following standards:

Functional	ISO/IEC 8802-3, IEEE 802.3, IEEE 802.3u, IEEE 802.1D
Safety	UL 1950, EN 60950, CSA 22.2#950, IEC 60950
EMC	EN 55022 Class B*, VCCI Class B*, AS/NZS3548 Class B*, FCC Part 15 Class A, ICES-003 Class A
	<small>* Category 5 screened cables must be used to ensure complete compliance with the Class B requirements of this standard. The use of unshielded cables (Category 3 or 5 for 10BASE-T ports or Category 5 for 100BASE-TX ports) complies with Class A requirements.</small>
Immunity	EN 50082-1 (IEC801 Parts 2–5)
Environmental	
Operating Temperature	0–50°C (32–122°F)
Humidity	0–95% (non-condensing)

Physical

Width	440 mm (17.3 in.)
Depth	173 mm (6.8 in.)
Height	44 mm (1.7 in.) or 1U
Weight	3C16592A: 2.22 kg (4.90 lb) 3C16593A: 2.10 kg (4.63 lb)

Mounting

Free standing, or 19-in. rack mounted using the mounting kit supplied

Electrical

Power Inlet	IEC 320
AC Line Frequency	50/60 Hz
Power Consumption	3C16592A: 25 VA 3C16593A: 42 VA
Power Dissipation	3C16592A: 86 BTU/hr 3C16593A: 142 BTU/hr
Input Voltage	100–240 VAC
Current Rating	3C16592A: 1.0 A (maximum) 3C16593A: 1.0 A (maximum)



SAFETY INFORMATION

Please read the following safety information carefully before installing the Baseline Dual Speed Hub.



WARNING: Installation and removal of the unit must be carried out by qualified personnel only.

- If installing the unit in a stack with SuperStack II Hub units, the Baseline Dual Speed Hub must be installed beneath narrower Hub units.
- Do not connect the unit to an A.C. outlet (power supply) without an Earth (ground) connection.
- The unit must be connected to an earthed (grounded) outlet to comply with international safety standards.
- The appliance coupler (the connector to the unit and not the wall plug) must have a configuration for mating with an EN60320/IEC320 appliance inlet.
- The socket outlet must be near to the unit and easily accessible. You can only remove power from the unit by disconnecting the power cord from the outlet.
- This unit operates under SELV (Safety Extra Low Voltage) conditions according to IEC 60950. The conditions are only maintained if the equipment to which it is connected also operates under SELV conditions.
- Only connect a 3Com *Advanced Redundant Power System* (3C16070, 3C16071 or 3C16071A) to the *Redundant Power System* socket.

France and Peru only

This unit cannot be powered from IT[†] supplies. If your supplies are of IT type, this unit must be powered by 230V (2P+T) via an isolation transformer

ratio 1:1, with the secondary connection point labelled Neutral, connected directly to Earth (ground).

Power Cord Set

This must be approved for the country where it will be used.

- | | |
|-------------------|--|
| U.S.A. and Canada | <ul style="list-style-type: none"> ■ The cord set must be UL-approved and CSA certified. ■ The minimum specifications for the flexible cord are: <ul style="list-style-type: none"> - No. 18 AWG - Type SV or SJ - 3-conductor ■ The cord set must have a rated current capacity of at least 10A. ■ The attachment plug must be an earth-grounding type with a NEMA 5-15P (15A, 125V) or NEMA 6-15P (15A, 250V) configuration. |
| United Kingdom | <ul style="list-style-type: none"> ■ The supply plug must comply with BS1363 (3-pin 13-amp) and be fitted with a 5A fuse which complies with BS1362. ■ The mains cord must be <HAR> or <BASEC> marked and be of type HO3VVF3GO.75 (minimum). |
| Europe | <ul style="list-style-type: none"> ■ The supply plug must comply with CEE7/7 ("SCHUKO") ■ The mains cord must be <HAR> or <BASEC> marked and be of type HO3VVF3GO.75 (minimum). |
| Denmark | <ul style="list-style-type: none"> ■ The supply plug must comply with section 107-2-D1, standard DK2-1a or DK2-5a. |
| Switzerland | <ul style="list-style-type: none"> ■ The supply plug must comply with SEV/ASE 1011. |

[†]Impédance à la terre



CONSIGNES IMPORTANTES DE SÉCURITÉ

Veillez lire à fond l'information de la sécurité suivante avant d'installer le Baseline Dual Speed Hub.



AVERTISSEMENT: L'installation et la dépose de ce groupe doivent être confiés à un personnel qualifié.

- Si vous entassez l'unité avec les unités SuperStack II Hub, l'unité Baseline Dual Speed Hub doit être installée en dessous des unités Hub plus étroites.
- Ne branchez pas votre appareil sur une prise secteur (alimentation électrique) lorsqu'il n'y a pas de connexion de mise à la terre (mise à la masse).
- Vous devez raccorder ce groupe à une sortie mise à la terre (mise à la masse) afin de respecter les normes internationales de sécurité.
- Le coupleur d'appareil (le connecteur du groupe et non pas la prise murale) doit respecter une configuration qui permet un branchement sur une entrée d'appareil EN60320/CEI 320.
- La prise secteur doit se trouver à proximité de l'appareil et son accès doit être facile. Vous ne pouvez mettre l'appareil hors circuit qu'en débranchant son cordon électrique au niveau de cette prise.
- L'appareil fonctionne à une tension extrêmement basse de sécurité qui est conforme à la norme IEC 60950. Ces conditions ne sont maintenues que si l'équipement auquel il est raccordé fonctionne dans les mêmes conditions.
- Branchez uniquement un 3Com *Advanced Redundant Power System* (3C16070, 3C16071 or 3C16071A) sur la prise femelle du *Redundant Power System*.

France et Pérou uniquement:

Ce groupe ne peut pas être alimenté par un dispositif à impédance à la terre.

Si vos alimentations sont du type impédance à la terre, ce groupe doit être alimenté par une tension de 230 V (2 P+T) par le biais d'un transformateur d'isolement à rapport 1:1, avec un point secondaire de connexion portant l'appellation Neutre et avec raccordement direct à la terre (masse).

Cordon électrique

Il doit être agréé dans le pays d'utilisation.

- | | |
|----------------------|--|
| Etats-Unis et Canada | <ul style="list-style-type: none"> ■ Le cordon doit avoir reçu l'homologation des UL et un certificat de la CSA. ■ Le cordon souple doit respecter, à titre minimum, les spécifications suivantes: <ul style="list-style-type: none"> - calibre 18 AWG - type SV ou SJ - à 3 conducteurs ■ Le cordon doit être en mesure d'acheminer un courant nominal d'au moins 10 A. ■ La prise femelle de branchement doit être du type à mise à la terre (mise à la masse) et respecter la configuration NEMA 5-15P (15 A, 125 V) ou NEMA 6-15P (15 A, 250 V). |
| Europe | <ul style="list-style-type: none"> ■ La prise secteur doit être conforme aux normes CEE 7/7 ("SCHUKO") ■ LE cordon secteur doit porter la mention <HAR> ou <BASEC> et doit être de type HO3VVF3GO.75 (minimum). |
| Danemark | <ul style="list-style-type: none"> ■ La prise mâle d'alimentation doit respecter la section 107-2 D1 de la norme DK2 1a ou DK2 5a. |
| Suisse | <ul style="list-style-type: none"> ■ La prise mâle d'alimentation doit respecter la norme SEV/ASE 1011. |



WICHTIGE SICHERHEITSINFORMATIONEN

Bitte unbedingt vor dem Einbauen des Baseline Dual Speed Hub Einheit die folgenden Sicherheitsanweisungen durchlesen.



WARNUNG: Die Installation und der Ausbau des Geräts darf nur durch Fachpersonal erfolgen.

- Wenn die Baseline Dual Speed Hub Einheit in einer Stapel mit anderen SuperStack II Hub Einheiten eingebaut werden soll, muß die Baseline Dual Speed Hub Einheit unter die schmalere Hub Einheiten eingebaut werden.
- Das Gerät nicht an eine Wechselstromsteckdose anschließen, die nicht geerdet ist.
- Das Gerät muß an eine geerdete Steckdose angeschlossen werden, die die internationalen Sicherheitsnormen erfüllt.
- Der Gerätestecker (der Anschluß an das Gerät, nicht der Wandsteckdosenstecker) muß eine passende Konfiguration für einen Geräteeingang gemäß EN60320/IEC320 haben.
- Die Netzsteckdose muß in der Nähe des Geräts und leicht zugänglich sein. Die Stromversorgung des Geräts kann nur durch Herausziehen des Geräternetzkaabels aus der Netzsteckdose unterbrochen werden.

- Der Betrieb dieses Geräts erfolgt unter den SELV-Bedingungen (Sicherheitskleinstspannung) gemäß IEC 60950. Diese Bedingungen sind nur gegeben, wenn auch die an das Gerät angeschlossenen Geräte unter SELV-Bedingungen betrieben werden.
- Nur ein 3Com *Advanced Redundant Power System* (3C16070, 3C16071 or 3C16071A) an den *Redundant Power System* Anschluß anschließen.

Stromkabel

Dies muss von dem Land, in dem es benutzt wird geprüft werden:

- | | |
|---------|---|
| Europe | <ul style="list-style-type: none"> ■ Das Netzkabel muß vom Typ HO3VVF3GO.75 (Mindestanforderung) sein und die Aufschrift <HAR> oder <BASEC> tragen. ■ Der Netzstecker muß die Norm CEE 7/7 erfüllen ("SCHUKO"). |
| Schweiz | <ul style="list-style-type: none"> ■ Dieser Stromstecker muß die SEV/ASE 1011 Bestimmungen einhalten. |



LIFETIME LIMITED WARRANTY

This warranty applies to customers located in the United States, Australia, Canada (except Quebec), Ireland, New Zealand, U.K., and other English language countries, and countries for which a translation into the local language is not provided.

SuperStack® II Baseline Dual Speed Hub

Hardware

3Com warrants to the end user ("Customer") that this hardware product will be free from defects in workmanship and materials, under normal use and service, for the following length of time from the date of purchase from 3Com or its authorized reseller:

Lifetime, for as long as the original Customer owns the product (not transferable to a subsequent end user).

3Com's sole obligation under this express warranty shall be, at 3Com's option and expense, to repair the defective product or part, deliver to Customer an equivalent product or part to replace the defective item, or if neither of the two foregoing options is reasonably available, 3Com may, in its sole discretion, refund to Customer the purchase price paid for the defective product. All products that are replaced will become the property of 3Com. Replacement products or parts may be new or reconditioned. 3Com warrants any replaced or repaired product or part for ninety (90) days from shipment, or the remainder of the initial warranty period, whichever is longer.

Software

3Com warrants to Customer that each software program licensed from it, except as noted below, will perform in substantial conformance to its program specifications, for a period of ninety (90) days from the date of purchase from 3Com or its authorized reseller. 3Com warrants the media containing software against failure during the warranty period. No updates are provided, unless specifically included in the Included Services section. 3Com's sole obligation under this express warranty shall be, at 3Com's option and expense, to refund the purchase price paid by Customer for any defective software product, or to replace any defective media with software which substantially conforms to applicable 3Com published specifications. Customer assumes responsibility for the selection of the appropriate applications program and associated reference materials. 3Com makes no warranty or representation that its software products will meet Customer's requirements or work in combination with any hardware or applications software products provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected. For any third party products listed in the 3Com software product documentation or specifications as being compatible, 3Com will make reasonable efforts to provide compatibility, except where the non-compatibility is caused by a "bug" or defect in the third party's product or from use of the software product not in accordance with 3Com's published specifications or user manual.

THIS 3COM PRODUCT MAY INCLUDE OR BE BUNDLED WITH (1) THIRD PARTY SOFTWARE, OR (2) 3COM SOFTWARE THAT IS LICENSED "AS IS", THE USE OF WHICH IS GOVERNED BY A SEPARATE END USER LICENSE AGREEMENT. THIS 3COM WARRANTY DOES NOT APPLY TO SUCH THIRD PARTY SOFTWARE OR 3COM SOFTWARE LICENSED "AS IS". FOR THE APPLICABLE WARRANTY, PLEASE REFER TO THE END USER LICENSE AGREEMENT GOVERNING THE USE OF SUCH SOFTWARE OR THE ACCOMPANYING DOCUMENTATION RELATING TO SUCH SOFTWARE.

Year 2000 Warranty

In addition to the Hardware Warranty and Software Warranty stated above, 3Com warrants that each product sold or licensed to Customer on and after January 1, 1998 that is date sensitive will continue performing properly with regard to such date data on and after January 1, 2000, provided that all other products used by Customer in connection or combination with the 3Com product, including hardware, software, and firmware, accurately exchange date data with the 3Com product, with the exception of those products identified at 3Com's Web site, <http://www.3com.com/products/yr2000.html>, as not meeting this standard. If it appears that any product that is stated to meet this standard does not perform properly with regard to such date data on and after January 1, 2000, and Customer notifies 3Com within ninety (90) days after purchase of the product from 3Com or its authorized reseller, 3Com shall, at its option and expense, provide a software update which would effect the proper performance of such product, repair such product, deliver to Customer an equivalent product to replace such product, or if none of the foregoing is feasible, refund to Customer the purchase price paid for such product. Any software update or replaced or repaired product will carry a Year 2000 Warranty for ninety (90) days after purchase.

Obtaining Warranty Service

Customer must contact a 3Com Corporate Service Center or an Authorized 3Com Service Center within the applicable warranty period to obtain warranty service authorization. Dated proof of purchase from 3Com or its authorized reseller may be required. Products returned to 3Com's Corporate Service Center must be pre-authorized by 3Com with a User Service Order (USO) number (or a Return Material Authorization (RMA) number or a Service Repair Order (SRO) number, whichever was issued) marked on the outside of the package, and sent prepaid and packaged appropriately for safe shipment, and it is recommended that they be insured or sent by a method that provides for tracking of the package. Responsibility for loss or damage does not transfer to 3Com until the returned item is received by 3Com. The repaired or replaced item will be shipped to Customer, at 3Com's expense, not later than thirty (30) days after 3Com receives the defective product, and 3Com will retain risk of loss or damage until the item is delivered to Customer.

3Com shall not be responsible for any software, firmware, information, or memory data of Customer contained in, stored on, or integrated with any products returned to 3Com for repair, whether under warranty or not.

Dead- or Defective-on-Arrival. In the event a product completely fails to function or exhibits a defect in materials or workmanship within the first forty-eight (48) hours of installation but no later than thirty (30) days after the date of purchase, and this is verified by 3Com, it will be considered dead- or defective-on-arrival (DOA) and a replacement shall be provided prior to 3Com receiving the defective product, but only if Customer provides a purchase order number, credit card number, or other method of payment acceptable to 3Com, to be used if 3Com needs to charge Customer for the replacement, as explained below. The replacement product will normally be shipped not later than three (3) business days after 3Com's verification of the DOA product, but may be delayed due to export or import procedures. The shipment of a replacement product prior to 3Com receiving the

defective product is subject to local legal requirements and may not be available in all locations. When such a replacement is provided and Customer fails to return the original product to 3Com within fifteen (15) days after shipment of the replacement, 3Com will charge Customer for the replacement product, at list price.

Shipment of a Replacement Prior to 3Com Receiving the Defective Product is provided for five (5) years, after which time it may be available for a specified fee, but in either case only if Customer provides a purchase order number, credit card number, or other method of payment acceptable to 3Com, to be used if 3Com needs to charge Customer for the replacement, as explained below. 3Com will make commercially reasonable efforts to ship the replacement product not later than five (5) business days after receiving the request for a replacement, but may be delayed due to product availability or export or import procedures. The shipment of a replacement product prior to 3Com receiving the defective product is subject to local legal requirements and may not be available in all locations. When such a replacement is provided and Customer fails to return the original product to 3Com within fifteen (15) days after shipment of the replacement, 3Com will charge Customer for the replacement, at list price. This replacement prior to 3Com receiving the defective product is different from the fee-based Advance Hardware Replacement Service, which is available as a contracted service offering.

Included Services

3Com's Electronic Support Services, available at no charge, include 3Com Knowledgebase, information on known bugs, documentation, release notes, and publicly available software and firmware upgrades. 3Com reserves the right to modify or cancel this offering at any time, without advance notice.

Telephone Technical Support, with coverage for basic troubleshooting only, will be provided at no additional charge for ninety (90) days from the date of purchase, on a commercially reasonable efforts basis. Telephone support is provided by 3Com only if Customer purchased this product directly from 3Com, or if Customer's reseller is unable to provide telephone support. To qualify for this telephone technical support, Customer must register on the 3Com Web site at <http://support.3com.com/index.htm>, and state the date of purchase, product number, and serial number. 3Com's response to a request for telephone technical support will be in the form of a return call from a 3Com representative by close of business the following business day, defined as 9 a.m. to 5 p.m., local time, Monday through Friday, excluding local holidays. Please refer to the Technical Support appendix in the User Guide for telephone numbers.

Software Updates, All software and firmware upgrades and the latest code for this product downloaded through the 3Com Software Library.

Warranties Exclusive

IF A 3COM PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY FOR BREACH OF THAT WARRANTY SHALL BE REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT 3COM'S OPTION. TO THE FULL EXTENT ALLOWED BY LAW, THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, TERMS, OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES, TERMS, OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, SATISFACTORY QUALITY, CORRESPONDENCE WITH DESCRIPTION, AND NON-INFRINGEMENT, ALL OF WHICH ARE EXPRESSLY DISCLAIMED. 3COM NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS.

3COM SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT OR MALFUNCTION IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO OPEN, REPAIR OR MODIFY THE PRODUCT, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, POWER CUTS OR OUTAGES, OTHER HAZARDS, OR ACTS OF GOD.

Limitation of Liability

TO THE FULL EXTENT ALLOWED BY LAW, 3COM ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF 3COM OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT 3COM'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Disclaimer

Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages for certain products supplied to consumers, or the limitation of liability for personal injury, so the above limitations and exclusions may be limited in their application to you. When the implied warranties are not allowed to be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights which may vary depending on local law.

Governing Law

This Limited Warranty shall be governed by the laws of the State of California, U.S.A., and by the laws of the United States, excluding their conflicts of laws principles. The United Nations Convention on Contracts for the International Sale of Goods is hereby excluded in its entirety from application to this Limited Warranty.

3Com Corporation

5400 Bayfront Plaza
P.O. Box 58145
Santa Clara, CA 95052-8145
(408) 326-5000
May, 2000

3Com reserves the right to modify or cancel this offering at any time, without advance notice. This offering is not available where prohibited or restricted by law.



ELECTRO-MAGNETIC COMPATIBILITY

FCC Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference to radio communications, in which case the user will be required to correct the interference at their own expense.

Information To The User

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the equipment with respect to the receiver.
- Move the equipment away from the receiver.
- Plug the equipment into a different outlet so that equipment and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

How to Identify and Resolve Radio-TV Interference Problems

This booklet is available from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

In order to meet FCC emissions limits, this equipment must be used only with cables which comply with IEEE 802.3.

CSA Statement

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

VCCI Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス B 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

BSMI Statement

警告使用者：這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。



TECHNICAL SUPPORT

The following numbers may be used for technical support:

Country	Telephone Number	Country	Telephone Number
Asia, Pacific Rim			
Australia	1 800 678 515	P.R. of China	10800 61 00137 or 021 6350 1590
Hong Kong	800 933 486		800 6161 463
India	+61 2 9937 5085	Singapore	
Indonesia	001 800 61 009	S. Korea	
Japan	0031 61 6439	From anywhere in S. Korea:	00798 611 2230
Malaysia	1800 801 777	From Seoul:	(0)2 3455 6455
New Zealand	0800 446 398	Taiwan, R.O.C.	0080 611 261
Pakistan	+61 2 9937 5085	Thailand	001 800 611 2000
Philippines	1235 61 266 2602		
Europe			
From anywhere in Europe, call:	+31 (0)30 6029900 phone		
	+31 (0)30 6029999 fax		
Europe, South Africa, and Middle East			
From the following countries, you may use the toll-free numbers:			
Austria	0800 297468	Netherlands	0800 0227788
Belgium	0800 71429	Norway	800 11376
Denmark	800 17309	Poland	00800 3111206
Finland	0800 113153	Portugal	0800 831416
France	0800 917959	South Africa	0800 995014
Germany	0800 1821502	Spain	900 983125
Hungary	00800 12813	Sweden	020 795482
Ireland	1800 553117	Switzerland	0800 55 3072
Israel	1800 9453794	U.K.	0800 966197
Italy	1678 79489		
Latin America			
Argentina	AT&T +800 666 5065	Mexico	01 800 CARE (01 800 2273)
Brazil	0800 13 3266	Peru	AT&T +800 666 5065
Chile	1230 020 0645	Puerto Rico	800 666 5065
Colombia	98012 2127	Venezuela	AT&T +800 666 5065
North America			
	1 800 876-3266		



PRODUCTS

The SuperStack II Baseline Dual Speed Hub is part of the extensive SuperStack II range of 3Com products. This range includes hubs, switches, power systems and other networking equipment, and is continually being developed. Contact your supplier for the latest product information and to order these products.

Product Registration

You can now register your SuperStack II Switch on the 3Com web site to receive up-to-date information on your product:

<http://www.3com.com/productreg/pdd>

Feedback

Your suggestions are very important to us. They will help make our documentation more useful to you. Please e-mail comments about this document to 3Com at: pddtechpubs_comments@3Com.com

Please include the following information when commenting: the document title, part number (shown at the bottom of page 8), and page number, if appropriate.

Environmental Statement

It is the policy of 3Com Corporation to be environmentally-friendly in all operations. To uphold our policy, we are committed to:

- Establishing environmental performance standards that comply with national legislation and regulations.
- Conserving energy, materials and natural resources in all operations.
- Reducing the waste generated by all operations.
- Ensuring that all waste conforms to recognized environmental standards.
- Maximizing the recyclable and reusable content of all products.
- Ensuring that all products can be recycled, reused and disposed of safely.
- Ensuring that all products are labelled according to recognized environmental standards.
- Improving our environmental record on a continual basis.



LEGAL NOTICES

© 3Com Technologies, 2000. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without permission from 3Com Technologies.

3Com Technologies reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Technologies to provide notification of such revision or change.

3Com Technologies provides this documentation without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

UNITED STATES GOVERNMENT LEGENDS:

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following restricted rights:

For units of the Department of Defense:

Restricted Rights Legend: Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) for restricted Rights in Technical Data and Computer Software clause at 48 C.F.R. 52.227-7013. 3Com Centre, Boundary Way, Maylands Park South, Hemel Hempstead, Herts, HP2 7YU, U.K.

For civilian agencies:

Restricted Rights Legend: Use, reproduction or disclosure is subject to restrictions set forth in subparagraph (a) through (d) of the Commercial Computer Software - Restricted Rights Clause at 48 C.F.R. 52.227-19 and the limitations set forth in 3Com Corporation's standard commercial agreement for the software. Unpublished rights reserved under the copyright laws of the United States.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation, or on the removable media in a directory file named `license.txt`. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com and SuperStack are registered trademarks of 3Com Corporation.

Other brand and product names may be registered trademarks or trademarks of their respective holders.